4x4 / 8x8 DVI Matrix Switch with Scaler

VM5404D / VM5808D

User Manual

www.aten.com

EMC Information

FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

CE Warning: This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

KCC Statement
유선 제품용 / A 급 기기 (업무용 방송 통신 기기)
이 기기는 업무용 (A 급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며 , 가정 외의 지역에서 사용하는 것을 목적으로 합니다 .

RoHS

This product is RoHS compliant.

Safety

This product has been classified as Information Technology Equipment.

SJ/T 11364-2006

The following contains information that relates to China.

部件名称	有毒有害物质或元素					
	铅	汞	镉	六价铬	多溴联苯	多溴二苯醚
电器部件	●	○	○	○	○	○
机构部件	○	○	○	○	○	○

○: 表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T 11363-2006规定的限量要求之下。

●: 表示符合欧盟的豁免条款，但该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T 11363-2006的限量要求。

×: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T 11363-2006的限量要求。

User Information

Online Registration

Be sure to register your product at our online support center:

International	http://eservice.aten.com

Telephone Support

For telephone support, call this number:

International	886-2-8692-6959
China	86-10-5255-0110
Japan	81-3-5615-5811
Korea	82-2-467-6789
North America	1-888-999-ATEN ext 4988
United Kingdom	44-8-4481-58923

User Notice

All information, documentation, and specifications contained in this manual are subject to change without prior notification by the manufacturer. The manufacturer makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties as to merchantability or fitness for any particular purpose. Any of the manufacturer's software described in this manual is sold or licensed *as is*. Should the programs prove defective following their purchase, the buyer (and not the manufacturer, its distributor, or its dealer), assumes the entire cost of all necessary servicing, repair and any incidental or consequential damages resulting from any defect in the software.

The manufacturer of this system is not responsible for any radio and/or TV interference caused by unauthorized modifications to this device. It is the responsibility of the user to correct such interference.

The manufacturer is not responsible for any damage incurred in the operation of this system if the correct operational voltage setting was not selected prior to operation. PLEASE VERIFY THAT THE VOLTAGE SETTING IS CORRECT BEFORE USE.

Package Contents

The VM5404D / VM5808D package consists of:

- 1 VM5404D / VM5808D DVI Matrix Switch with Scaler
- 1 Power Cord
- 1 IR Remote Control
- 1 IR Receiver
- 1 Mounting Kit
- 1 User Instructions*

Check to make sure that all the components are present and that nothing got damaged in shipping. If you encounter a problem, contact your dealer.

Read this manual thoroughly and follow the installation and operation procedures carefully to prevent any damage to the unit, and/or any of the devices connected to it.

***** Features may have been added to the VM5404D / VM5808D since this manual was published. Please visit our website to download the most up-to-date version.

© Copyright 2015 ATEN® International Co., Ltd.
Manual Date: 2015-09-10
ATEN and the ATEN logo are registered trademarks of ATEN International Co., Ltd. All rights reserved.
All other brand names and trademarks are the registered property of their respective owners.

Contents

EMC Information ii
RoHS ii
Safety iii
SJ/T 11364-2006 iii
User Information iv
Online Registration iv
Telephone Support iv
User Notice iv
Package Contents v
Contents vi
About this Manual x
Conventions xi
Product Information xi

Chapter 1.
Introduction
Overview 1
Features 2
Requirements 3
Source Devices 3
Display Devices 3
Cables 3
Source Device Operating Systems 4
Components 5
VM5404D Front View 5
VM5404D Rear View 6
VM5808D Front View 7
VM5808D Rear View 8
IR Remote Control 9

Chapter 2.
Hardware Setup
Rack Mounting 11
Grounding 12
Cable Connection 13
Installation Diagram 14

Chapter 3.
Front Panel Configuration
Overview 15
Front Panel Pushbuttons 15
Enter Password 16

Main Screen 17
Port Switching 17
Input Port Selection 17
Output Port Selection 19
LCD Menu Organization 21
Menu Pushbutton 21
IP Setting 22
IP Address / Subnet Mask 22
Gateway 22
Serial Port Setting 23
Baud Rate 23
Operation Mode 24
EDID Mode 24
OSD 25
Output Status 26
Security Mode 27
Password 27
Change Password 28
Save to a Profile 29
Play/Stop the Profile Schedule 30
Profile Pushbutton 31
IR Remote Control Operation 32
Change the Input source of an Output display 32
Power on/off individual Output displays 32
Power on/off all Output displays 33

Chapter 4.
Browser Operation

Overview 35
Logging In 35
Main Page 36
Menu Bar 36
Profile List 37
Adding/Playing a Profile 37
Profile List Options 39
Profile 39
Play Window 39
Profile Scheduling 41
Connection Profiles 43
Digital Signage Profile 43
Output Icon 44
Select Source 44
Grid View 45
Output Options 45
Video Wall Profile 46
Video Wall Options 46

Number of Displays / Bezel Dimensions 47
Blank Output 48
Independent Output 49
Grouping 49
Group 50
Display Preferences 50
Video Wall Example 51
Output Options 52
DVI Video Options. 52
System Settings 54
General 55
Fan Status 55
OSD. 55
Other 55
User Account. 57
Add Account 58
Permission Level 59
Port Name 60
Network 61
EDID 62
EDID Mode 63
Customized Mode 64
EDID & CEA Description 65
Customized EDID Settings 66
Firmware 69
HDCP 70
Telnet Operation 71
Configuration Menu 71
1. H – Call up the command list for help 71
2. GT – Set gateway address 72
3. IM – Set IP subnet mask 72
4. IP – Set IP address 72
5. LO – Load connections from profile 72
6. PW – Change password 72
7. RI – Read what input is connected to nn output 72
8. RO – Read what output is connected to nn input 73
9. SB – Set serial port baud rate 73
10. SS – Switch input to specified output 73
11. SV – Save the current connections into a profile 73
12. TI – Set timeout 73
13. VR – Software version information 73

Chapter 5.
RS-232 Commands

Serial Control Protocol Commands 75
RS232 Pin Assignment 75

Configuring the Serial Port 75
Verification 76
Switch Port Command 77
EDID Mode Command 79
Mute Command 81
Scaling Command 82
Fan Speed Command 85
Echo Command 86
Black Screen Command 87
Read Command 88
Reset Command 89
Baud Rate Command 90
Save/Load Profile Command 91
OSD Command 92

Appendix

Safety Instructions 93
General 93
Rack Mounting 95
Technical Support 96
International 96
North America 96
Specifications 97
Limited Warranty 98

About this Manual

This User Manual is provided to help you get the most from your VM5404D / VM5808D system. It covers all aspects of installation, configuration and operation. An overview of the information found in the manual is provided below.

Chapter 1, Introduction, introduces you to the VM5404D / VM5808D system. Its purpose, features and benefits are presented, and its front and back panel components are described.

Chapter 2, Hardware Setup, describes how to set up your VM5404D / VM5808D installation.

Chapter 3, Front Panel Configuration, explains the fundamental concepts involved in operating the VM5404D / VM5808D at the local site via the front panel LCD display using pushbuttons.

Chapter 4, Browser Operation, provides a complete description of the VM5404D / VM5808D's Browser Graphical User Interface (GUI), and how to use it to remotely configure and operate the VM5404D / VM5808D.

Chapter 5, RS-232 Protocol Commands, provides a complete list of the serial control protocol commands used when utilizing the RS-232 Serial Port so that an extra source device can be utilized in the installation.

An Appendix, provides specifications and other technical information regarding the VM5404D / VM5808D.

Conventions

This manual uses the following conventions:

`Monospaced`	Indicates text that you should key in.
[ ]	Indicates keys you should press. For example, [Enter] means to press the **Enter** key. If keys need to be chorded, they appear together in the same bracket with a plus sign between them: [Ctrl+Alt].
1.	Numbered lists represent procedures with sequential steps.
♦	Bullet lists provide information, but do not involve sequential steps.
→	Indicates selecting the option (on a menu or dialog box, for example), that comes next. For example, Start → Run means to open the *Start* menu, and then select *Run*.
	Indicates critical information.

Product Information

For information about all ATEN products and how they can help you connect without limits, visit ATEN on the Web or contact an ATEN Authorized Reseller. Visit ATEN on the Web for a list of locations and telephone numbers:

International	http://www.aten.com
North America	http://www.aten-usa.com

This Page Intentionally Left Blank

Chapter 1
Introduction

Overview

The ATEN VanCryst VM5404D / VM5808D 4 x 4 / 8 x 8 DVI Matrix Switch with Scaler is a versatile solution that provides an easy way to route high definition video and audio from any of 4/8 DVI sources to any of 4/8 DVI displays at the same time. As a Matrix Switch, each input can be independently connected to any or all outputs, giving you the ultimate in flexibility and control in any multi-display audio/video installation.

The VM5404D / VM5808D features Seamless Switching, which employs FPGA matrix system architecture to seamlessly switch between multiple sources and multiple displays. With EDID Expert technology, the VM5404D / VM5808D selects the optimum EDID settings for smooth power-up and the highest quality display. It also features a high-performing scaling engine that converts the video resolution into the display's native resolution to give you the best image quality.

You can easily configure the VM5404D / VM5808D via the front panel LCD display and pushbuttons, and through the use of an IR Remote Control. The LCD provides a quick view of all port connections, and lets operators access the unit's built-in configuration utility.

Furthermore, the VM5404D / VM5808D allows convenient configuration and operation via an intuitive Graphical User Interface (GUI) using any web browser. The web GUI provides you with advanced features which include easy setup of custom Video Wall and Digital Signage configurations that can be saved and recalled. Because your VM5404D / VM5808D can be controlled over a standard TCP/IP connection, it conveniently integrates into any existing network for easy remote access. For complete system and install integration, serial control is standard through the VM5404D / VM5808D's built-in RS-232 port that allows the switch to be controlled through a high-end controller or PC.

The VM5404D / VM5808D is an ideal solution for applications that require DVI outputs from multiple sources to be conveniently delivered to multiple destinations, such as for stage presentations, competitions, control centers, and system installations that require real-time reports.

Features

- 4x4 or 8x8 DVI I/O connections
- Configuration and Control via Front panel LCD display / pushbuttons / IR Remote Control
- System Operation via bi-directional RS-232 serial controller / Internet browser-based (web) Graphical User Interface (GUI) / Telnet
- Extends IR transmission via IR extension cable
- Scaler – features a video scaling function to integrate a video wall seamlessly with various output video formats
- Seamless Switch™ – features close-to-zero second switching that provides continuous video streams, real-time switching and stable signal transmissions
- Video Wall – features up to 8 video wall profiles for custom screen layouts via a point-n-click web GUI
- EDID Expert – configures optimum EDID settings for smooth power-up, high-quality display and use of the best resolution across different screens
- Firmware Upgradeable
- Rack Mountable (1U Design)

Requirements

The following devices are required for a complete VM5404D / VM5808D installation:

Source Devices

- Computer or A/V source device with DVI Type A output connector(s)

Note: A DVI/HDMI adapter is required when connecting a HDMI source device.

Display Devices

- Display devices or receivers with an DVI input connector

Cables

- 1 DVI cable for each source device you will be connecting
- 1 DVI cable for each display device you will be connecting
- 1 Cat 5e cable
- 1 RS-232 serial cable

Note: No cables are included in this package. We strongly recommend that you purchase high-quality cables of appropriate length since this will affect the quality of the audio and video display. Contact your dealer to purchase the correct cable sets.

Source Device Operating Systems

Supported operating systems are shown in the table below:

OS		Version
Windows		2000 and higher
Linux	RedHat	6.0 and higher
	SuSE	8.2 and higher
	Mandriva (Mandrake)	9.0 and higher
UNIX	AIX	4.3 and higher
	FreeBSD	3.51 and higher
	Sun	Solaris 8 and higher
Novell	Netware	5.0 and higher
Mac		OS 9 and higher
DOS		6.2 and higher

Components

VM5404D Front View



No.	Component	Description
1	LCD Display	The LCD Display gives a quick view of all port connections, and shows the various options for configuring and operating the VM5404D. For full details, see *Main Screen*, page 17.
2	Input Pushbuttons	These pushbuttons refer to the DVI Input ports found on the VM5404D rear panel. Press to select the Input port. These pushbuttons may also correspond to menu options, connection profiles (P1–P4) and so on. **Note:** The **INPUT** (1–4) front panel pushbuttons have built-in LEDs that light to indicate they have been selected.
3	Output Pushbuttons	These pushbuttons refer to the DVI Output ports found on the VM5404D rear panel. Press to select the Output port. These pushbuttons may also correspond to connection profiles (P5–P8). **Note:** The **OUTPUT** (1–4) front panel pushbuttons have built-in LEDs that light to indicate they have been selected.
4	Prev / Next Pushbuttons	These pushbuttons allow you to cycle through the menu options on the LCD display.
5	Function Pushbuttons	The function pushbuttons (**MENU**, **PROFILE**, **ENTER** and **CANCEL**) are for navigating the LCD built-in configuration utility. For full details, see *Front Panel Pushbuttons*, **page 15**. **Note:** The **MENU** and **PROFILE** front panel pushbuttons have built-in LEDs that light to indicate they have been selected.

VM5404D Rear View



No.	Component	Description
1	Power Socket	This is a standard 3-pin AC power socket. The power cord from an AC source plugs in here.
2	Power Switch	This is a standard rocker switch that powers the unit on and off.
3	Grounding Terminal	The grounding wire attaches here. See *Grounding*, page 12, for further details.
4	DVI Output Ports	The cables from your DVI source devices plug into these ports.
5	DVI Input Ports	The cables from your DVI display devices plug into these ports.
6	IR Port	Connect the IR Receiver unit included with your product via this 3.5 mm Mini Stereo Jack.
7	RS-232 Serial Port	Connect a computer or high-end system controller via this serial port.
8	Ethernet Port	In order to access the VM5404D's Browser Graphical User Interface (GUI), the VM5404D must be connected to your network. The cable that connects the VM5404D to your LAN plugs in here. See *Cable Connection*, page 13, for further details

VM5808D Front View



No.	Component	Description
1	LCD Display	The LCD Display gives a quick view of all port connections, and shows the various options for configuring and operating the VM5808D. For full details, see *Main Screen*, page 17.
2	Input Pushbuttons	These pushbuttons refer to the DVI Input ports found on the VM5808D rear panel. Press to select the Input port. These pushbuttons may also correspond to menu options, connection profiles (P1–P8) and so on. **Note:** The **INPUT** (1–8) front panel pushbuttons have built-in LEDs that light to indicate they have been selected.
3	Output Pushbuttons	These pushbuttons refer to the DVI Output ports found on the VM5808D rear panel. Press to select the Output port. These pushbuttons may also correspond to connection profiles (P9–P16). **Note:** The **OUTPUT** (1–8) front panel pushbuttons have built-in LEDs that light to indicate they have been selected.
4	Function Pushbuttons	The function pushbuttons (**MENU**, **PROFILE**, **ENTER** and **CANCEL**) are for navigating the LCD built-in configuration utility. For full details, see *Front Panel Pushbuttons***, page 15**. **Note:** The **MENU** and P**ROFILE** front panel pushbuttons have built-in LEDs that light to indicate they have been selected.

VM5808D Rear View



No.	Component	Description
1	Power Socket	This is a standard 3-pin AC power socket. The power cord from an AC source plugs in here.
2	Power Switch	This is a standard rocker switch that powers the unit on and off.
3	Grounding Terminal	The grounding wire attaches here. See *Grounding*, page 12, for further details.
4	DVI Input Ports	The cables from your DVI source devices plug into these ports.
5	DVI Output Ports	The cables from your DVI display devices plug into these ports.
6	IR Port	Connect the IR Receiver unit included with your product via this 3.5 mm Mini Stereo Jack.
7	RS-232 Serial Port	Connect a computer or high-end system controller via this serial port.
8	Ethernet Port	In order to access the VM5808D's Browser Graphical User Interface (GUI), the VM5808D must be connected to your network. The cable that connects the VM5808D to your LAN plugs in here. See *Cable Connection*, page 13, for further details

IR Remote Control



No.	Component	Description
1	Power ON/OFF	Use the **ON** and **OFF** pushbuttons to turn the Output displays on or off – by individual port, or all ports. (see *IR Remote Control Operation*, page 32)
2	Output Pushbuttons 1–8	Press **Output** display pushbuttons 1–8 to select the Output display you want to configure (see *IR Remote Control Operation*, page 32).
3	Input Pushbuttons 1–8	Press **Input** source pushbuttons 1–8 to select the Input source you want to display on a selected output (see *IR Remote Control Operation*, page 32).

Note: The VM5404D's IR remote control only supports use of the 1~4 Input and 1~4 Output pushbuttons.

This Page Intentionally Left Blank

Chapter 2
Hardware Setup

1. Important safety information regarding the placement of this device is provided on page 93. Please review it before proceeding.
2. Make sure that the power to all devices connected to the installation are turned off. You must unplug the power cords of any computers that have the Keyboard Power On function.

Rack Mounting

The VM5404D / VM5808D can be mounted in a 19" (1U) system rack. For the most convenient front panel pushbutton configuration and operation at the local site, mount the unit at the front of the rack, as follows:

1. Use the M3 x 8 Phillips head hex screws supplied with the Mounting Kit to screw the rack mounting brackets onto the front of the unit.



2. Position the unit in the front of the rack and align the holes in the mounting brackets with the holes in the rack.
3. Screw the mounting brackets to the rack.

Grounding

To prevent damage to your installation, it is important that all devices are properly grounded.

1. Use a grounding wire to ground the VM5404D / VM5808D by connecting one end of the wire to the grounding terminal, and the other end of the wire to a suitable grounded object.



2. Make sure that all devices in your VM5404D / VM5808D installation are properly grounded.

Cable Connection

Installation of the VM5404D / VM5808D is simply a matter of connecting the appropriate cables. Refer to the installation diagram on the following page (the numbers in the diagram correspond to the steps below), and do the following:

1. Use a grounding wire to ground the unit by connecting one end of the wire to the grounding terminal, and the other end of the wire to a suitable grounded object.

   Note: Do not omit this step. Proper grounding helps to prevent damage to the unit from surges or static electricity.

2. Connect up to 4 (VM5404D) or 8 (VM5808D) DVI video sources to the **DVI Input** ports
3. Connect up to 4 (VM5404D) or 8 (VM5808D) DVI display devices to the **DVI Output** ports
4. Connect the IR Receiver into the **IR** port.
5. (Optional) If using the Browser Operation features (see *Browser Operation*, page 35), plug a Cat 5e cable from the LAN into the VM5404D / VM5808D's **Ethernet** port.
6. (Optional) If you are using the serial control function, use an appropriate RS-232 serial cable to connect the computer or serial controller to the VM5404D / VM5808D's female **RS-232 Serial** port.
7. Plug the power cord supplied with the package into the VM5404D / VM5808D's 3-prong AC socket, and then into an AC power source.
8. Power on the VM5404D / VM5808D and all devices in the installation.

Installation Diagram



Chapter 3
Front Panel Configuration

Overview

The VM5404D / VM5808D can be configured and operated locally via the front panel LCD/pushbuttons and IR Remote Control; remotely over a standard TCP/IP connection via graphical user interface (GUI) using a web browser; via a remote terminal session using Telnet; or by a RS-232 serial controller.

The local front panel operation is discussed in this chapter. Web GUI Operation is discussed in Chapter 4, and RS-232 serial control is discussed in Chapter 5.

Front Panel Pushbuttons

The front panel features an LCD display and pushbuttons for convenient operation locally. This allows users to perform operations such as selecting which source shows on which display, viewing the IP settings, configuring the serial port, setting the EDID Mode / OSD / Output Status, selecting security settings, and loading/saving profiles.

Note the following front panel pushbutton functions:

- Use the **MENU** pushbutton to access the Menu page options: IP Setting, Serial Port Setting, Operation Mode, Security Mode, and Save to a Profile (see *LCD Menu Organization*, page 21).
- Use the **PROFILE** pushbutton to switch between the connection profiles which have been added to the Profile List (see *Profile List*, page 37). Pressing this pushbutton for longer than 3 seconds displays the Save to a Profile page (see *Save to a Profile*, page 29).
- Use the **CANCEL** pushbutton to go back to a previous page, return to the Main Screen, stop or exit an operation.
- Use the **ENTER** pushbutton to select options and confirm operations.
- Use the **INPUT / OUTPUT** (**1**–**8**) or **(1-4)** pushbuttons to select the Input/ Output port. These pushbuttons may also correspond to menu options, connection profiles, and so on.
- The VM5404D provides **Prev** / **Next** pushbuttons to navigate the menus.
- Use pushbuttons **7/8** (Prev/Next) to navigate the VM5808D menus.

Enter Password

Upon VM5404D / VM5808D startup, check the front panel LCD to view the loading progress. If the Password screen / LCD Menu fails to load, an error message displays. Reset the unit and try again.

If you are accessing the VM5404D / VM5808D for the first time, the Password screen appears as soon as the LCD loading process is done. Enter the default password 1234 to continue to the Main Screen (see *Main Screen*, page 17).



Additionally, the Password Screen appears if the VM5404D / VM5808D has been configured to require a password for Front Panel operation (see *Security Mode*, page 27).

To enter a password, do the following:

1. In the **Enter Password** field, check that the cursor is at the first asterisk (*) and flashing.
2. Use the front panel Input Port pushbuttons (1–8) or (1–4) to enter the 4-digit password. After the fourth digit has been entered correctly, the Main Screen displays.
3. Press **Cancel** to clear the password. The digits revert to 4 asterisks and the cursor goes back to the first asterisk.

Note: 1. The VM5404D / VM5808D password can be any four digit combination between 1111 to 8888 (VM5808D) or 1111 to 4444 (VM5404D). The default password is 1234.

2. If you enter an incorrect password, the cursor goes back to the first digit and reverts to flashing. The Incorrect Password message displays at the bottom of the screen, but clears as soon as a new password is entered.
3. If Password option is Enabled (see *Security Mode*, page 27), the LCD display time-out is 5 minutes by default.

Main Screen

The Main Screen shows the Input ports in the top row, which are tied to the Output ports shown in sequential order (1–8) at the bottom row.



- The front panel pushbutton label (1–8) corresponds to the **Input** ports and **Output** ports on the unit's rear panel.
- Use the **Menu** pushbutton to view the LCD Menu (see *LCD Menu Organization*, page 21).
- Use the **Profile** pushbutton to switch between profile connections (see *Profile List*, page 37).

Port Switching

From the Main Screen, users can configure the Input-to-Output port connections to associate an Input source device to an Output display.

Input Port Selection

Use the Input Port pushbuttons to select the Input port you want to configure.



To select which input source displays on each output port, do the following:

1. Press any Input port pushbutton (1–8). The Output port LED(s) tied to the said Input port light(s) up (steady).

   In the example below, pressing Input port **1** shows it is tied to Output ports **1** and **2**.

(Continues on next page.)

(Continued from previous page.)

2. To disconnect an Output port from an Input port, press the corresponding Output port pushbutton.

   In the example below, Output port **2** has been disconnected from Input port **1**.

3. To switch to another Input port, press any Input port pushbutton. The Output port LED(s) tied to the said Input port light(s) up (steady).

   In the example below, pressing Input port **2** shows it is tied to Output ports **3** and **4**.

4. To connect Output port **2** to Input port **2**, press the Output port **2** pushbutton. The Output port 2 LED flashes (0.5 sec on, 0.2 sec off). As a result, Input port **2** is now connected to Output ports **2**, **3** and **4**.



Once the signal from the selected Input port is successfully tied to the Output port, the LEDs turn off and the LCD information is updated.

Note: 1. Pressing an Input port a second time deselects it.

2. Input ports that are not configured or tied to any output port shows **NA** in the LCD screen.

3. Pressing the **Cancel** pushbutton once stops the Input Port Selection operation, and the LCD displays the active setting. Pressing the **Cancel** pushbutton again turns all LEDs off.

4. After 10 seconds of inactivity, all the LEDs turn off.

Output Port Selection

Use the Output Port pushbuttons to select the Output port you want to configure.



To select which output display corresponds to each input source device, do the following:

1. Press any Output port pushbutton (1–8).

   In the example below, Output port **1** pushbutton has been pressed. It is not tied to any Input port.

2. If an Output port pushbutton is pressed a second time, it is deselected and the LED turns off.

3. To connect the selected Output port(s) to an Input port, press the Input port pushbutton. to which you want the Output port(s) tied. The newly selected Input port LED flashes (0.5 sec on, 0.2 sec off), and the LCD information is updated.

   In the example below, pressing Input port **2** ties it to Output ports **2**, **3** and **4**.

   

4. To switch Output ports **2, 3** and **4** to another Input port (and disconnect it from Input port **2**), press another Input port pushbutton to which you want it tied.

   In the example below, Input port **3** has been pressed and is now connected to Output ports **2**, **3** and **4**.

Note: 1. Pressing an Output port a second time deselects it.

2. Pressing the **Cancel** pushbutton once stops the Output Port Selection operation, and the LCD displays the active setting. Pressing the **Cancel** pushbutton again turns all LEDs off.
3. After 10 seconds of inactivity, all the LEDs turn off.

LCD Menu Organization

The VM5404D / VM5808D has a built-in configuration utility via the front panel LCD, which can be controlled by pressing the **MENU** and front panel Input pushbuttons (1–8). User can cycle through the menu options, starting from IP Setting page, in the order shown in the table below:

Menu Page	Sub-Menu Page(s)		
IP Setting	IP Address		
	Subnet Mask		
	Gateway		
Serial Port Setting	Baud Rate	9600 / **19200** / 38400 / 115200	
Operation Mode	EDID	**Default** / Port1 / Remix / Customized	
	CEC	On / **NA**	
	OSD	**On** / NA	
	Output Status	**On** / NA	
Security Mode	Password	**Enable** / Disable	
	Change Password	Old Password	New Password
Save to a Profile	Save to a Profile No.	01–08 (VM5404D); 01-16 (VM5808D)	
Play/Stop the Profile Schedule			

Note: The highlighted values are the default settings of the VM5404D / VM5808D.

Menu Pushbutton

Press the **MENU** pushbutton to switch between the Main Screen and LCD Menu page. When the Menu is active, the MENU pushbutton's built-in LED lights up:

From the Menu page:

- Press **1** to go to the IP Setting page (see *IP Setting*, page 22)
- Press **2** to go to the Serial Port Setting page (see *Serial Port Setting*, page 23)
- Press **8/Next** to go to the next page(s) for the sub-menu pages

- Press **Menu** or **Cancel** to return to the Main Screen

IP Setting

The IP Setting page displays the VM5404D / VM5808D's IP configuration. The values in the LCD Menu are read-only and can be edited via the Browser GUI (*Telnet Operation*, page 71).

IP Address / Subnet Mask

To view the VM5404D / VM5808D's IP address and Subnet Mask, do the following:

1. From the Menu page, press **1** to see the IP Setting submenu. The IP address and Subnet Mask are then shown.



Note: The VM5404D / VM5808D default IP address is 192.168.0.60. The default Subnet Mask is 255.255.255.0

2. Press **8/Next** to go to the next page.
3. Press **Menu** to return to the Menu page.
4. Press **Cancel** to return to the previous page without saving.

Gateway

To view the VM5404D / VM5808D's gateway address, do the following:

1. From the Menu page, press **1** to see the IP Setting submenu, then press **8** to get to the next page. The gateway address displays.

Note: The default Gateway is 192.168.0.1.

2. Press **7/Prev** to go to the previous page.
3. Press **Menu** to return to the Menu page.
4. Press **Cancel** to return to the previous page without saving.

Serial Port Setting

To configure the VM5404D / VM5808D's baud rate for its serial port connection, select Serial Port Setting from the Menu page.

Baud Rate

To set the VM5404D / VM5808D's baud rate, do the following:

1. Select **Baud Rate Setting** from the Serial Port Setting submenu by pressing **1**:



2. Press pushbuttons 1–4 to make your selection.



   Baud Rate options are:

   - **1:** 9600
   - **2**: 19200
   - **3**: 38400
   - **4**: 115200

   Note: The default baud rate is 19200.

3. Press **Menu** to return to the Menu page.
4. Press **Cancel** to return to the previous step without saving.

Operation Mode

The EDID Mode, OSD and Output Status features can be configured from the Operation Mode page.

- EDID (Extended Display Identification Data) is used to have the VM5404D / VM5808D automatically apply a preset video configuration or EDID Mode, which utilizes the best resolution across different monitors
- The OSD, when enabled for a port, lets an attached display/monitor show real-time port switching information
- The Output Status shows whether the video/audio of an Output port is turned on or off

To configure the VM5404D / VM5808D's operation mode settings from the Main Screen, use the **Menu** pushbutton to access the Menu page, press **8/Next** to navigate to the next page, then press pushbutton **1** to access the Operation Mode page.



EDID Mode

To configure the EDID Mode, do the following:

1. From the Operation Mode page, press pushbutton **1**:



(Continues on next page.)

2. Press pushbuttons 1–4 to make your selection.

EDID Mode options are:

EDID Option	Description
1: Port1	The EDID from port1 is passed to all video sources.
2: Default	The default EDID is passed to all video sources.
3: Remix	Uses the EDID of each connected display according to its connection when the VM5404D / VM5808D is first powered on, or immediately after pressing 3 to select the Remix option.
4: Customized	Automatically retrieves and saves the EDID settings of a connected monitor/display device to an input source port. This can be configured using the Browser GUI. See *Customized EDID Settings*, page 66.

3. Press **Menu** to return to the Menu page.
4. Press **Cancel** to return to the previous step without saving.

OSD

The On-Screen Display or OSD feature enables real-time text updates to appear on the display device's screen for any configuration changes made to the Output port via the VM5404D / VM5808D's front panel, IR remote control or Browser GUI.

To configure the OSD setting for each output port, do the following:

1. From the Operation Mode page, press **8/Next** to go to the next page, then press pushbutton **1**:

2. Press pushbuttons 1–8 to enable (**ON**) or disable (**NA**) the OSD feature for the output port.

Note: The default OSD setting is On.

3. Press **Menu** to return to the Menu page.
4. Press **Cancel** to return to the previous step without saving.

Output Status

To configure the Output Status settings for each output port, do the following:

1. From the Operation Mode page, press **8/Next** to go to the next page, then press pushbutton **2**:

2. Press pushbuttons 1–8 to enable (**ON**) or disable (**NA**) the video/audio of the output port.



Note: The default Output Status setting is On.

3. Press **Menu** to return to the Menu page.
4. Press **Cancel** to return to the previous step without saving.

Security Mode

The Security Mode page allows users to manage the VM5404D / VM5808D's password-related settings; the **Password** page configures the VM5404D / VM5808D to require a password for local operation after the LCD display times out or is powered off/on; the **Change Password** option allows users to set a new password for the VM5404D / VM5808D.

To configure the VM5404D / VM5808D's password settings from the Main Screen, use the **Menu** pushbutton to access the Menu page, press **8/Next** to navigate to the next pages, then press pushbutton **2** to access the Security Mode page.

Password

1. To set the VM5404D / VM5808D to require a password for local operation, press pushbutton **1**.



2. To require a password after the LCD display times out or is powered off/on, press pushbutton **1**. Otherwise, press pushbutton **2**.



Note: If Password is Enabled, the LCD display's default time-out is 5 minutes.

3. Press **Menu** to return to the Menu page.
4. Press **Cancel** to return to the previous step without saving.

Change Password

1. To change the password for accessing the unit, press pushbutton **2**.



2. In the Old Password field, the cursor flashes at the first digit. Enter the old password (see *Enter Password*, page 16). If the old password is entered correctly, you can proceed to the next step.



Note: If you entered an incorrect password, an error message appears and the cursor goes back to the first digit (flashing). The Incorrect Password message clears as soon as a new digit is entered.

3. In the New Password field, the cursor flashes at the first digit. Enter the new password using the front panel number pushbuttons (1111–8888).



4. Re-enter the new password in the following screen. The new password is applied by the VM5404D / VM5808D immediately.



If the password you entered does not match the one entered in the previous screen, an error message appears. Enter the new password correctly.

5. Press **Menu** to return to the Menu page.
6. Press **Cancel** to return to the previous step without saving.

Save to a Profile

The switch allows users to store up to 8 (VM5404D) or 16 (VM5808D) (numbered P1–P16) different connection profiles that can be saved and recalled later.

The active Input-to-Output port connections on the LCD Main Screen is the configuration saved to a profile. When a user loads a profile, the change is immediate and the profile number is shown on the lower right corner of the LCD screen.

To save a profile once the desired port connections are set, do the following:

1. Press the **Menu** pushbutton to access the Menu page, then **8/Next** to navigate to the next pages. Press pushbutton **1** to open the select Save to a Profile page.

2. On the page that opens, you are asked to give the profile a number. Use the front panel number pushbuttons to select a profile number into which you want to save the configuration.



   VM5404D: Options are P1–P8 (when saving a profile via the LCD), where:

   - Input port pushbuttons **1–4** correspond to Profile **P1** to **P4**
   - Output port pushbuttons **1–4** correspond to Profile **P5** to **P8**

   VM5808D: Options are P1–P16 (when saving a profile via the LCD), where:

   - Input port pushbuttons **1–8** correspond to Profile **P1** to **P8**
   - Output port pushbuttons **1–8** correspond to Profile **P9** to **P16**

3. Press **Enter** to store the configuration – the LCD shows Profile Saved.
4. Press **Menu** to return to the Menu page,
5. Press **Cancel** to return to the previous step without saving.

Note: Access the Save to a Profile page quickly by pressing the **Profile** pushbutton for longer than 3 seconds.

Play/Stop the Profile Schedule

Inputting port pushbutton **2** will Play or Stop the active Profile Schedule.

Profile Pushbutton

The **PROFILE** pushbutton lets users conveniently switch between connection profiles that have been saved or added to the Profile List (see *Profile List*, page 37).

If a Profile is in use, its profile number (P1–P32) is shown on the lower right corner of the LCD display.



The Profile pushbutton functions as follows:

- Press the Profile pushbutton for 1–2 seconds to cycle between profiles stored in the GUI's Profile List (from 1 up to 16, depending on how many are added to the list)
- Alternatively, after pressing the Profile pushbutton (lights), use the Input/ Output pushbuttons to switch to a specific profile (from P1 to P16 only). Note that:
  - **Input** ports **1–8** or **1-4** correspond to Profile **P1** to **P8** or **P1** to **P4**
  - **Output** ports **1–8** or **1-4** correspond to Profile **P9** to **P16** or **P5** to **P8** (where Output Port 1=Profile 9, Output Port 2=Profile 10... Output Port 8=Profile 16)

  The selected pushbutton lights steady, and the VM5404D / VM5808D immediately applies the port connections configured in the selected profile.
- When the Profile pushbutton is pressed for 3 seconds or more, the LCD directs to the Save to a Profile page (see *Save to a Profile*, page 29)
- Press the **Cancel** pushbutton to exit

Note: If there are no profiles configured on the VM5404D / VM5808D device, an error message "*No Profile List defined. Profile List can be edited via the Web GUI*" is displayed when the Profile pushbutton is pressed.

A Profile's port connections can be edited using the front panel pushbuttons (see *Port Switching*, page 17) or via the *Connections* page of the Browser GUI (see *Main Page*, page 36). Additionally, the Profile List can be configured via the Profile page of the Browser GUI (see *Profile List*, page 37).

IR Remote Control Operation

The IR remote control (*IR Remote Control*, page 9) included with the VM5404D / VM5808D can be used to:

- change the Input source of any Output display
- power on/off individual Output displays; or
- power on/off all Output displays simultaneously

Before using the remote control, a user must first plug the IR External Receiver into the rear panel of the VM5404D / VM5808D and place the receiver where the IR signal can be reached (see *IR Port*, page 8).

Change the Input source of an Output display

To change the Input source of an Output display, using the remote control, do the following:

1. Press the **Output** port number (**1–8**) or (**1-4**) you want to change.
2. Within 2 seconds press the **Input** port number (**1–8**) or (**1-4**) you want the Output port to display.*
3. Repeat steps 1-2 to change additional ports.

*For the change to occur the Input number must be pressed within 2 seconds of pressing the Output number.

Power on/off individual Output displays

To power on/off individual Output displays, using the remote control, do the following:

1. Press the **Output** port number (**1–8**) or (**1-4**) you want to power on/off.
2. Within 2 seconds press the **ON** or **OFF** pushbutton.*
3. Repeat steps 1-2 to change the power status back on/off.

*If the **ON** or **OFF** pushbutton is pressed *after* 2 seconds of pressing the Output port number, all the displays are powered on or off instead of just the intended Output port.

Power on/off all Output displays

To power on/off all Output displays simultaneously, with the remote control, do the following:

1. Press the **ON** or **OFF** pushbutton.*
2. Repeat step 1 to simultaneously change back the power status of all Output ports, to on or off, respectively.

*The **ON** or **OFF** pushbuttons bring all displays to the same power status, regardless of the individual power statuses.

This Page Intentionally Left Blank

Chapter 4
Browser Operation

Overview

The VM5404D / VM5808D can be configured over a standard TCP/IP connection via its built-in Graphical User Interface (GUI). Because it can be accessed from anywhere over a network or the Internet, operators can easily log in via web browser. Security is ensured by password protection and user-configurable time-out. The VM5404D / VM5808D supports three levels of remote users with various privileges, and up to 32 users can log into the GUI at one time. For full details, see the sections that follow.

Logging In

To access the GUI, type the VM5404D / VM5808D's IP address into the address bar of any browser. If a Security Alert dialog box appears, accept the certificate – it can be trusted. The login screen appears:



- The default IP address is **http://192.168.0.60**
- The default Username and Password are: **administrator / password**
- Enter the username and password, then click **Login**.
- The same user can not be logged in simultaneously.
- Use the drop-down menu to select the GUI language
  - English, French, German, Italian, Japanese, Korean, Portuguese, Russian, Spanish, Simplified Chinese and Traditional Chinese

Note: The username supports lower case letters only.

Main Page

The Main Page opens to the **Profile List**. This is where you configure the input to output connections by creating profiles. The page is divided into three parts: the *Menu Bar*, *Profile List*, and *Profile Scheduling*.



Menu Bar

The Menu Bar consists of the *Settings* icon and *Logout* button.



- Click **Settings** to enter the System Settings (see page 54).
- Click the **Logout** button to log out of the GUI.

Profile List

The *Profile List* lets you configure the input to output port connections by creating profiles to use. You can store up to 8 (VM5404D) or 16 (VM5808D) differently configured profiles that can be saved and played by two methods: locally via the unit's front panel pushbuttons and via the web GUI.



Adding/Playing a Profile

To configure a connection profile:

1. From the Profile List, click a **[Profile]**.
2. Select the profile type:



Digital Signage: Select this option for video that is displayed independently on separate monitors (page 43).

Video Wall: Select this option for monitors that are displayed together - tiled or as a large screen (page 46).

3. Configure the input to output connections for a Digital Signage (**page 43**) or Video Wall **(page 46**) profile.

4. New profiles appear in the *Profile List*, as shown here:



5. Select the profile and click **Apply.**

6. The profile appears in the large **Play** window and the connections start:



Note: More information about Profile List options are provided on the next page.

Profile List Options

Clicking a *Profile* or the *Play* window opens a pop-up menu with options.

Profile



Option	Description
Apply	Click **Apply** to put the profile in the Play window. This allows you to start the profile connections.
Edit	Click **Edit** to configure the profile's input to output connections.

Play Window



Option	Description
Show OSD	Check **Show OSD** to show/hide current connection information that appears on the display.
Mute All	Check **Mute All** to mute the audio for all ports.
Blank All	Check **Blank All** to turn off the video to all displays.
On Sequence	**On Sequence** will appear when a profile schedule is playing.
<	Click < to go back to the previous profile in the sequence, when Profile Scheduling is in use. Only available with *On Sequence* (see page 41).
>	Click > to advance to the next profile in the sequence, when Profile Scheduling is in use. Only available with *On Sequence*.

Option	Description
Positioning	Click **Positioning** to open a window that allows you to adjust the image position on each display. For Video Wall profiles, you can also set the Bezel Dimension, which is the frame thickness between each display.
Remove	Removes the profile from the Play window.
Edit	Click **Edit** to configure the profile's input to output connections.

Profile Scheduling

Profile Scheduling is located below the Profile List. Scheduling allows you to queue and play connection profiles in sequence for a specific amount of time.



Option	Description
	Click to edit profile schedule.
	Click to play profile schedule. **Note:** When profiles that are part of schedule are playing, *On Sequence* will appear in the Play Window. 
	Click to stop profile schedule.
	Click to change to next or previous profile.

After selecting **Edit**, you will be presented with the following options.



Option	Description
	Click to add profiles to the schedule in the order to be played, left to right, then set the amount of time each profile plays.
	Click a profile for a pop-up menu to appear: ◆ Select **Startup** to use the profile as the starting point for the schedule. ◆ Click **Replace** to replace the selected profile with another profile. ◆ Click **Remove** to delete the profile from the schedule. ◆ Use **< >** to change the profile's position in the schedule.
	Use the drop-down menu to select the duration (Hours, Minutes, or Seconds) and enter the amount of time for the profile to play. After the time expires, the schedule switches to the next profile. Use **Repeat** to stop switching between schedules and stay on the currently selected profile. If **Repeat** isn't used, the schedule will loop back to the first profile. If **Repeat** is used, a specific number of hours, minutes and seconds cannot be set and later profiles will not be played.
Save	Click **Save** to save the schedule as it appears. After saving, the Profile Scheduling window will close. When a Profile Schedule is playing the *On Sequence* box will appear in the Play window.
Cancel	Click **Cancel** to discard changes and return to the Profile Schedule page.

Connection Profiles

There are two types of profiles: *Digital Signage* and *Video Wall*. **Digital Signage** profiles are for displays where video is viewed on separate monitors.**Video Wall** profiles are for displays that are tiled together, where multiple monitors form one large screen – in various arrangements.



Digital Signage Profile

Each icon represents an output port and the connected display. The large number is the **Input** port selected for the display. The small number (upper-left corner) is the **Output** port for the display. Click the icons to select options.



- Select icons to choose the **Video Input** from the *Select Source* menu.
- Click the PEN icon or name to edit the profile name.
- Click **Select All** to select all outputs.
- Click **Unselect All** to unselect all outputs.
- Click **Save** to save the profile or **Save as** to save as a different profile number.
- Click *Grid View* to use an alternate method for configuring connection profiles (see page 45).

Output Icon

Option	Description
Output Icon	Click an Output icon(s) to highlight it in green and use the *Select Source* menu to set the video options (see *Select Source* below). The large number is the **Video Input** port selected for the display. The small number (upper-left corner) is the **Output** port of the display.
Mute / Video	Click the **speaker** icon to mute the audio on/off. Click the **video** icon to turn the video off/on.

Select Source



Option	Description
Select Source	The Select Source menu appears when you click an **Output** icon.
Output	Displays the Outputs that are selected for the configuration change.
Video Input	Use the drop-down menu to select the **Video Input**. Click **Save** or **Save as** to save the changes.
Radio Button	◆ **Fit Width of Output(s)**: fits the video to the width of the display. ◆ **Fit Height of Output(s)**: fits the video to the height of the display. ◆ **Scale to Whole Output(s)**: fits the video on the entire display.

Grid View

The Grid View allows you to select the **Input** to **Output** connections using a simple grid.



- From an *Output Port* column, click a box to select it's **Input Port**. The box will turn orange.
- **Uncheck** an *Output Port* box to disable the video for that Output Port. The column will turn dark grey.
- **Check** an *Output Port* box to enable the video for that Output Port.
- Click **Save** to save the profile. Click **Save as** to save as a different profile number.

Output Options

For instructions on the *Output Options*, see *Output Options*, page 52.

Video Wall Profile

Each blank icon represents an Output port and the connected display. Use the icons to create Independent and Grouped Outputs. **Independent** Outputs will display video on a single monitor. **Grouped** Outputs will display video across multiple monitors as one large screen.



Video Wall Options

- Click an icon to choose its **Output** and **Video Input** from the *Display Preference* menu (see page 49).
- Click multiple icons to Group Outputs (see *Grouping*, page 49) and choose the **Video Input** from the *Display Preference* menu.
- Use + next to **Display Layout _1** to create additional layouts under the same profile.
- Click the PEN icon or name to edit the profile name.
- Click **Select All** to select all outputs.
- Click **Unselect All** to unselect all outputs.
- Click **Save** to save the profile or **Save as** to save as a different profile number.
- Click **Save & Apply** to save the profile and put it in the Play window (see page 39).
- Click **Cancel** to discard changes and return to the Profile List.

Number of Displays / Bezel Dimensions



Option	Description
Number of Displays	Use the *Horizontal* and *Vertical* drop-down menu to select the number of displays that make up the video wall. Match this to the physical layout of the displays. Click **Apply** to set the layout.
Auto Fill	Click the *Auto Fill* checkbox and **Apply** to automatically incorporate all available outputs into the video wall.
Bezel Dimension	Use the four boxes to increase/decrease the frame size for each active display.
Monitor Lock / Unlock	Click the monitor icon to **Lock** the (4) bezel settings, so that when one size is changed they all change. Click the monitor icon to **Unlock** the (4) bezel settings, so that each size can be set independently.

Blank Output

Option	Description
Blank Icon	Click Blank Output icons to highlight icons in green and use the Display Preferences menu to set the video options (see *Display Preferences*, page 50). Select a **single** icon to set the **Output** and **Video Input** for an independent display (see *Independent Output*, page 49). Select **multiple** icons and set the **Video Input** to group displays as one screen (see *Grouping*, page 49). *You must first set the Output port for each icon*.
Drop-down Menu	Use the drop-down menu to select the Output port.

Independent Output

Option	Description
Independent Output	Independent Outputs are displays that have their own **Video Input** and **Output** selected. Independent Outputs: ◆ Display their own video ◆ Icons have their own color and Video Input Select an Independent Output and use the *Display Preferences* (page 50) menu select the **Video Input**.
Drop-down Menu	Use the drop-down menu to select the Output port.
Mute / Video	Click the **speaker** icon to mute the audio on/off. Click the **video** icon to turn the video off/on.

Grouping



Option	Description
Grouping	Click multiple icons to Group Outputs (highlighted in green) and click →|← to group the displays into one screen*. Use the **Display Preferences** menu to select the **Video Input** for the group - each Output icon in the Group will appear with the same Video Input number and icon color (see *Group*, page 50). **Note:** Before grouping you must set the Output port for each icon.
Ungroup	Select a group and click ←|→ to ungroup the displays.

Group

Option	Description
Group	A **Group** (of Outputs) shares the same **Video Input** and displays the video together as one large screen. A Group of Outputs: ◆ Displays video across multiple monitors to form one screen ◆ Icons have the same color and Video Input number. ◆ Select a Group and use the *Display Preferences* menu to select the **Video Input**. ◆ To group outputs see *Grouping*, page 49.
Mute / Video	Click the **speaker** icon to mute the audio on/off. Click the **video** icon to turn the video off/on.

Display Preferences



Option	Description
Display Preferences	Click Output icons for the Display Preferences menu to appear– to select the **Output** and/or **Video Input** port.
Output	Use the drop-down menu to select the **Output** port (Independent and single Blank icons only). If you select multiple displays the output ports selected will appear here. You can use the output icon's drop-down menu to change the output port for the display.

Option	Description
Video Input	Use the drop-down menu to select the **Video Input** port.
Radio Button	◆ **Fit Width of Output(s)**: fits the video to the width of the display. ◆ **Fit Height of Output(s)**: fits the video to the height of the display. ◆ **Scale to Whole Output(s)**: fits the video on the entire display.

Video Wall Example

The example below shows a video wall with 4 displays.



- Each Group and Independent Output has a unique color.
- This video wall has 1 **Group** and 2 **Independent** displays.
- The Group will show **Video Input 01** across both displays as one large screen.
- The Independent displays will show the video from their own **Video Input –** 03 and 04.
- Add Display Layouts to create separate video walls (see *Video Wall Options*, page 46).

Output Options

The *Output Option*s page is used to configure DVI Video options.



DVI Video Options

DVI Video Options allow you to set Seamless Switch options which determine how a display performs when the input port is changed.



- The *Transition*, *Period* and *Scale Resolution* apply only when Seamless Switching is on.

  - **Seamless Switch**: Turning *Seamless Switch* on removes the video distortion and delay seen when an input port is switched.
    - Use the drop-down menu to apply to all ports, or the ON/OFF button to enable/disable Seamless Switching per port.
  - **Transition**: Allows you to fade the video display when the input port is changed. Use the period option to set the fade speed.
    - Use the drop-down menu to apply to all ports, or ON/OFF button to enable/disable Transitions per port.
  - **Period**: Sets the fade speed for the Transition option.
    - Use the drop-down menu to apply an option (*Slow*, *Normal*, or *Fast*) to all ports, or lower drop-down menus to apply options per port.
  - **Scale Resolution**: Forces the port to scale the video displayed to the selected resolution.

- Use the top drop-down menu to apply an option to all ports, or lower drop-down menus to apply options per port.

- Click **Save** to save the profile or **Save as** to save as a different profile number.
- Click **Save & Apply** to save the profile and put it in the Play window (see page 39).
- Click **Cancel** to discard changes and return to the Profile List.

System Settings

Click the *Settings* link from the Main page for the System Settings to open on the **General** page:



- The *General* page allows you to edit Baud, language and OSD settings, and Fan information.
- The *User Account* page allows you to add and edit user accounts.
- The *Port Name* page allows you to name each input and output port.
- The *Network* page allows configuration of the network settings.
- The *EDID* page is used to set the EDID modes.
- The *Firmware* page is for upgrading the device's firmware.
- The *HDCP* page is lets users view and set HDCP key settings.
- Click **Back to Profile List** to return to the Main page.

General

The *General* page has three sections: Fan Status, OSD and Other.



Fan Status

- This section displays the VM5808D's two fans' statuses.
- The VM5808D also includes a drop-down menu which allows for manual selection of fan speed.

Note: If the fans have stopped working or are switched off, they will appear as follows.



OSD

- **OSD**: Sets the default OSD option for the port. When OSD is on: real-time text updates appear on the display for 10 seconds when configuration and port changes are made to the output.
  - Use the drop-down menu to apply options to all ports, or ON/OFF button to enable/disable the OSD for a port.
- Click **Save** to save the settings or **Cancel** to exit without saving the settings.

Other

- Use the **Language** drop-down menu to select a preferred user interface language.

- Options include: English, French, German, Italian, Japanese, Korean, Portuguese, Russian, Spanish, Simplified Chinese and Traditional Chinese.

- Use the **Baud Rate** drop-down menu to select a serial port setting.
  - Options include: 9600, 19200, 38400 and 115200.

User Account

The *User Account* page lets you add, edit, or delete users and change the password for accessing the VM5404D / VM5808D's GUI.

Note: This is an Administrator only function.



- **Add account** – Click the *Add account* button to add another user to the list. The VM5404D / VM5808D supports up to 32 users at one time (see page 58 for more details).
- **Edit** – Click the *Edit* button to change user information. This option allows an Administrator to edit individual accounts.

  - Edit – Rename the user account, set the password, add a description, and set the user's permission level (see page 58 for more details).
  - Delete – Removes the user account.

- The default username and password are: administrator/password.

Add Account

Use the Add Account / Edit buttons to create a user account, set the user's password, add a description, and set the user's permission level (see *Permission Level*, page 59) when accessing the VM5404D / VM5808D's GUI.



- Fill in a username or edit an existing one.
- Enter a password and re-type the password to confirm.

Note: Usernames and passwords accept multi-lingual characters, and must be 5–16 alphanumeric characters (excluding :;=[]+=/?\|). Passwords are case sensitive. Usernames only support lower case letters.

- Add or edit the description for the user.
- Select the permission level that you want to grant the user (see *Permission Level*, page 59).
- Click **Create User** to save the data.
- Click **Cancel** to discard the changes and exit.
- If a user is logged into the VM5404D / VM5808D's GUI, their user settings cannot be edited, and the fields in this screen are grayed out.

Permission Level

At the bottom of the New/Edit User page is the permission section, which is used to set a user's permission level.



The three available permission levels are as follows:

- **Administrator** – this level provides full access and control of the VM5404D / VM5808D, in addition to full User Management privileges.
- **Advanced User** – this level provides full access and control with no User Management privileges.
- **Basic User** – this level only provides basic functions (connections and open profiles).

Port Name

The *Port Name* page lets you name the input and output ports for easy identification.



- To name an Input/Output port, enter a descriptive name of up to 16 multi-language characters (excluding :;=[]+=/?\|) in the corresponding field and click **Save.**
- Language characters available include: English, French, German, Italian, Japanese, Korean, Portuguese, Russian, Spanish, Simplified Chinese and Traditional Chinese.
- To change an Input/Output port's name, enter another value and click **Save.**
- Input and Output port names can be the same.
- Press **Cancel** to go back a level, return to the initial screen, or exit.

Network

The *Network* page lets you configure the IP settings, website timeout, and Telnet settings for connecting to the VM5404D / VM5808D.



Enable DHCP to allow the DHCP server to assign an IP address to the VM5404D / VM5808D. Select **Disable** to enter your own static IP address settings for the device.

Click **Cancel** to use the following default values:

- IP Address – 192.168.0.60
- Subnet Mask – 255.255.255.0
- Default Gateway – 192.168.0.1
- Website Timeout* – 5 minutes
- Telnet Enabled

Enter the values, then click **Save**. Changes may take a few seconds and after refreshing the page automatically redirects you to the IP address specified.

***** This option controls how long an inactive web connection stays logged into the VM5404D / VM5808D. Use N/A to disable this option. Other options include 5, 10, 30 and 60 minutes. Any changes will take effect immediately.

EDID

The *EDID Settings* page lets users view and select an EDID Mode so that the VM5404D / VM5808D can use the best resolution for its display(s).



Note: The EDID Mode can also be selected via the Front Panel pushbuttons – see *EDID Mode*, page 24.

Extended Display Identification Data (EDID) is a data format that contains a display's basic information and is used to communicate with the video source/ system.

EDID Mode

In the left panel of the page, users can select a pre-configured EDID Mode using the **EDID Mode** radio buttons.



Select the EDID Mode to use and click **Apply**. The VM5404D / VM5808D uses the settings configured for that EDID mode.

Options are:

- **ATEN Default**: All ports' EDID are the same as the hardware default EDID.
- **Port 1 Mode**: All ports' EDID are the same as Port1's EDID.
- **Remix**: All ports' EDID use the best display resolution.
- **Customized**: See Customized Mode, see page 66.

Customized Mode

Use the *Customized* Mode to automatically retrieve and save the EDID settings of a connected monitor/display device to an input source port.



- In the left-most panel of the page, select **Customized** from the *EDID Mode* section and click **Apply.**
- **Port EDID Status**: Select which input source port you want to store the EDID configuration (01–08).
- **Retrieve EDID**: Click and a pop-up window appears to retrieve the EDID settings of a stored EDID configuration: *Customized EDID 01-08*, or *ATEN Default*. Select the port to retrieve:



- The right panel displays a summary of the acquired EDID settings that you can edit. Click **Save** and select the configuration for the **Current** or **All Ports** for the duration of the session.



EDID & CEA Description

The right panel of the screen lets users view the configuration of the *EDID* and *CEA* Modes selected:



- From the left column, click the option that you want to view and/or edit. There are two categories: **EDID** (Extended Display Identification Data) and **CEA** (Consumer Electronics Association).
- When you highlight the menu items on the left column, the right column displays the current settings for the corresponding EDID configuration. Some of the screens are read-only.
- See *Customized EDID Settings*, page 66 for more information on these two columns.

Customized EDID Settings

The EDID structure is comprised of 128 bytes in total – each heading shown in the left column corresponds to a specific number of bytes.

The pages for the pre-configured EDID Modes (Port 1, Default and Remix) cannot be edited. The pages for the Customized EDID, which can be edited, are discussed in the proceeding sections:

Established Timings

This page lists video resolutions/timings that display devices can support.



- Select the resolution(s) you want to use for the attached monitor/ display device.
- Click **Clear** to deselect all the items.
- Click **Select All** to check all the items.
- Click **Save** to apply the changes.

Standard Timings

This page shows eight resolutions/timings that display devices can support in addition to those listed in the Established Timings page.



- Select the *H Active Pixel* from the drop-down menu.
- Select the *Aspect Ratio* from the drop-down menu.
- Click **Save** to apply the changes.

Detail Timing / Display Description

This screen gives more video resolution options, and provides resolution/ timing details.



In the drop down menu, choose a resolution with values that fit the attached monitor/display device and click **Save**.

Monitor Description

This screen lets you specify the viewing specifications, namely horizontal and vertical scan ranges and pixel clock rate, of your monitor/display device.



Enter the values that correspond to your device and click **Save** to apply the changes.

Firmware

The *Firmware* page lets users view information about the firmware version currently in use and upgrade it if needed. This is an Administrator only function.



To upgrade the VM5404D / VM5808D's firmware, do the following:

1. Use the **Browse** button to locate the firmware upgrade file. Make sure you have the correct file saved on your PC.
2. Click **Upgrade** to begin the upgrade procedure.

Note: After updating the firmware, it's recommended that you clear your web browser's cache and then close and reopen the web browser. This will ensure the GUI refreshes and functions properly.

HDCP

The *HDCP* page lets users view and set HDCP key settings between input and output ports for digital copy protection and to ensure Seamless Switching between different devices. This is an Administrator and Advanced User only function.

Input

Here users can view whether the switch's content is HDCP or non-HDCP enabled.



Connection

Here users can find a visual display of connection paths between inputs and outputs. When selecting an input, its path is displayed in green.

Output

Here users can define whether or not HDCP settings are fixed, either by individual port or by applying one setting to all ports. By prearranging and fixing keys, this setting ensures that Seamless Switching is possible even when switching between HDCP and non-HDCP enabled devices.

Telnet Operation

The VM5404D / VM5808D can be operated and configured via a remote terminal session using Telnet.

To log into the VM5404D / VM5808D by means of a Telnet session, do the following:

1. On your computer, open a terminal (command line) session.
2. At the prompt, key in the VM5404D / VM5808D's IP address in the following way:

   ```
   telnet [IP address]:23
   ```

3. Press **Enter**. The login screen appears. At the login prompt, provide your Username and Password.

Note: If a user logs on using a Username that is already in session, the newest login takes effect and the previous session is replaced.

Configuration Menu

Once a Telnet connection to the VM5404D / VM5808D is established, the device's text-based Configuration Menu comes up, with the following items:

1. H – Call up the command list for help

Command list:

GT – Set gateway address

IM – Set IP subnet mask

IP – Set IP address

LO – Load connections from profile *nn*

PW – Change password

RI– Read what input is connected to *nn* output

RO – Read what output is connected to *nn* input

SB – Set the serial port baud rate

SS – Switch input to specified port

SV – Save the current connections into profile *nn*

TI – Set timeout

VR – Software version information

Ctrl-Q – Quit

2. GT – Set gateway address

```
GT
```

Old gateway address: 192.168.0.1

New gateway address:

3. IM – Set IP subnet mask

```
IM
```

Old IP subnet mask: 255.255.255.0

New IP subnet mask:

4. IP – Set IP address

```
IP
```

Old IP address: 192.168.0.60

New IP address:

5. LO – Load connections from profile

```
LO 01
```

Load profile 01 OK.

6. PW – Change password

```
PW
```

Old password: ********

New password:

7. RI – Read what input is connected to *nn* output

```
RI 01
```

Input port 02 04 08 is connected to output port 01

8. RO – Read what output is connected to *nn* input

```
RO 01
```

Output port 02 is connected to input port 01

9. SB – Set serial port baud rate

```
SB 96
```

Serial port baud rate is set to 9600

10. SS – Switch input to specified output

```
SS 01,03
```

Switch input 01 to output 03

11. SV – Save the current connections into a profile

```
SV 01
```

Save the current connections into profile 01

12. TI – Set timeout

```
TI 30
```

Set 30 minute timeout

13. VR – Software version information

```
VR
```

Software version 1.0.

Note: For further information about these functions, please reference the equivalent Browser GUI functions earlier in this chapter.

This Page Intentionally Left Blank

Chapter 5
RS-232 Commands

Serial Control Protocol Commands

The VM5404D / VM5808D's built-in bi-directional RS-232 serial interface allows system control through a high-end controller or PC. The RS-232 commands for the VM5404D and VM5808D are the same, with the only difference being that the VM5808D has 4 additional ports.

RS232 Pin Assignment

Pin	Description	Pin	Description
1	Not connected	6	Not connected
2	RXD	7	Not connected
3	TXD	8	Not connected
4	Not connected	9	Not connected
5	GND		



Configuring the Serial Port

The controller's serial port should be configured as follows:

Baud Rate	19200
Data Bits	8
Parity	None
Stop Bits	1
Flow Control	None

Verification

After entering a command, a verification message appears at the end of the command line as follows:

- **Command OK** - indicates that the command is correct and successfully performed by the switch
- **Command incorrect** - indicates that the command has the wrong format and/or values.

Switch Port Command

The Switch Port command allows you to switch ports on the VM5404D / VM5808D.

The formula for the Switch command is as follows:

Command + Input + Number + Output + Number + Control + [Enter]

1. For example, to switch input port 02 to output port 05, type:
   sw i02 o05 [Enter]
2. To switch output port 04 to the next port, type:
   sw o04 + **[Enter]**
3. To turn off video output on port 03, type:
   sw o03 off [Enter]

The following tables show the possible values for the **Switch Port** command:

Command	Description
sw	Switch command

Input Command	Description
i	Input command

Port number	Description
xx	01-08 port

Output Command	Description
o	Output command

Port number	Description
yy	01-08 port
*	All output ports

Control	Description
on	Turn on the display
off	Turn off the display
+	Next Port
-	Previous Port

Note: 1. By default, input port 01 is tied to output port 01; input port 02 is tied to output port 02; and so on until port 08 (i.e., o01 i01, o02 i02).

2. Each command string can be separated with a space.

3. The **Port Number** can be skipped, and the default value will be used.

The following table lists the available Switch Port commands:

Command	Input Command	Input Port	Output Command	Output Port	Control	Enter	Description
sw	i	xx	o	yy *		[Enter]	Switch Input Port xx to Output Port yy (xx:01~08; yy:01~08, *)
sw			o	yy *	on off	[Enter]	Turn on Output Port yy Turn off Output Port yy (yy:01~08, *)
sw			o	yy *	+ -	[Enter]	Switch Output port yy to next Output port. Switch Output port yy to previous Output port. (yy:01~08, *)

EDID Mode Command

Extended Display Identification Data (EDID) is a data that contains a display's basic information and is used to communicate with the video source.

The formula for the EDID command is as follows:

Command + Control + [Enter]

1. For example, to use the Port1 EDID mode, type:

   edid port1 [enter]

The following tables show the possible values for the **EDID** command:

Command	Description
edid	EDID Mode command

Control	Description
port1	Implement the EDID of the connected display to Port 1, and pass it to the video source.
remix	Implement the EDID of each connected display according to its connection when the VM5808D is first powered on, or immediately after selecting the Remix option.
default	Implements ATEN's default EDID. (default)
custom	Implements the customized mode as set in the EDID system settings. (See *Customized EDID Settings*, page 66)

Note: Each command string can be separated with a space.

The following table lists the available EDID commands:

Command	Control	Enter	Description
edid	port1	[Enter]	The EDID from Port 1 is passed to the video source.
edid	remix	[Enter]	The VM5404D / VM5808D implements the EDID of each connected display according to its connection when the VM5808D is first powered on, or immediately after selecting the Remix option.
edid	default	[Enter]	ATEN's default EDID is passed to the video source.

Command	Control	Enter	Description
EDID	custom	[Enter]	Implements the customized mode.

Mute Command

Mute allows you to enable or disable an output port(s) audio.

The formula for the Mute command is as follows:

Command + Output + Number + Control + [Enter]

1. For example, to mute the audio coming from output port 1, type:

   mute o01 on [enter]

The following tables show the possible values for the **Mute** command:

Command	Description
mute	Mute command

Output Command	Description
o	Output command

Port number	Description
yy	01-08 port (default is 01)
*	All output ports

Control	Description
on	Mute on; audio from DVI output port is disabled
off	Mute off; audio output enabled (default)

Note: 1. Each command string can be separated with a space.

2. Skip the output port command to mute or enable the audio of all output ports.

The following table lists the available Mute commands:

Command	Output Command	Output Port	Control	Enter	Description
mute	o	yy *	on	[Enter]	Audio on for output port yy (yy:01~08, *)
mute	o	yy *	off	[Enter]	Audio off for output port yy (default) (yy:01~08, *)

Scaling Command

The Scaling command allows you to set a resolution for scaling the display connected to an output port.

The formula for the Scaling command is as follows:

Command + Output + Number 1 + Horizontal Resolution + Number 2 + Vertical Resolution + Number 3 + Frequency + Number 4 + Control + [Enter]

1. For example, to turn scaling off for output port 02, type:

   scaling o02 off [Enter]

2. To set the scaling for output port 04 to 1920x1080@60Hz, type:

   scaling o04 1080p [Enter]

3. To set the scaling for all output ports to the connected display's native resolution, type:

   scaling o* native [Enter]

The following tables show the possible values for the **Scaling** command:

Command	Description
scaling	Scaling command

Output	Description
o	Output command

Port Number	Description
yy	01-08 port
*	All output ports

Horizontal Resolution	Description
hor	Horizontal resolution command for scaling

Resolution Number	Description
hhhh	Horizontal resolution

Vertical Resolution	Description
ver	Vertical resolution command for scaling

Resolution Number	Description
vvvv	Vertical resolution

Frequency	Description
freq	Frequency command for scaling

Frequency Number	Description
fff	Frequency resolution

Control	Description
off	Turn off the scaling function (by pass mode)
native	Map display's native resolution for scaling (default)

Note: 1. Each command string can be separated with a space.

2. The **Port Number** command string can be skipped, and the default value will be used.

The following table lists the available Scaling commands:

Command	Output	Port Number	Horizontal Resolution	Number	Vertical Resolution	Number	Frequency	Number	Control	Enter	Description
scaling	o	yy *							off	[Enter]	Turn off scaling for port yy (by pass mode) yy: 01 ~ 08 or *
scaling	o	yy *							native	[Enter]	Enable display's native resolution for scaling on output port yy (default) yy: 01 ~ 08 or *

Command	Output	Port Number	Horizontal Resolution	Number	Vertical Resolution	Number	Frequency	Number	Control	Enter	Description
scaling	o	yy *	hor	1920	ver	1080	freq	60		[Enter]	Scale output port yy to 1920x1080@60Hz yy: 01 ~ 08 or *
scaling	o	yy *	hor	1280	ver	720	freq	60		[Enter]	Scale output port yy to 1280x720@60Hz yy: 01 ~ 08 or *
scaling	o	yy *	hor	1920	ver	1200	freq	60		[Enter]	Scale output port yy to 1920x1200@60Hz yy: 01 ~ 08 or *
scaling	o	yy *	hor	1600	ver	1200	freq	60		[Enter]	Scale output port yy to 1600x1200@60Hz yy: 01 ~ 08 or *
scaling	o	yy *	hor	1400	ver	1050	freq	60		[Enter]	Scale output port yy to1400x1050@60Hz yy: 01 ~ 08 or *
scaling	o	yy *	hor	1280	ver	1024	freq	60		[Enter]	Scale output port yy to 1280x1024@60Hz yy: 01 ~ 08 or *
scaling	o	yy *	hor	1024	ver	768	freq	60		[Enter]	Scale output port yy to 1024x768@60Hz yy: 01 ~ 08 or *

Fan Speed Command

The Fan Speed command allows you to set the VM5808D's internal fan speed.

Note: This feature is not supported by the VM5404D.

To set the fan speed, use the following command:

Command + Control + [Enter]

1. For example, to set the fan to low speed, type:

   fan low [Enter]

The following tables show the possible values for the **Fan Speed** command:

Command	Description
fan	Fan Speed Command

Control	Description
low	Set internal fan to low speed (default)
mid	Set internal fan to normal speed
high	Set internal fan to high speed

Note: Each command string can be separated with a space.

The following table lists the available Fan Speed commands:

Command	Control	Enter	Description
fan	low	[Enter]	Sets fan speed to low
fan	mid	[Enter]	Sets fan speed to normal
fan	high	[Enter]	Sets fan speed to high

Echo Command

The Echo function updates the RS232 controller when operations are made via the front panel pushbuttons, web browser, or telnet. The changes echo back to the RS232 controller to keep the settings in sync with the device.

The formula for the Echo command is as follows:

Command + Control + [Enter]

1. For example, to enable the echo feature, type:

   echo on [Enter]

The following tables show the possible values for the **Echo** command:

Command	Description
echo	Echo command

Control	Description
on	Turns Echo function on
off	Turns Echo function off (default)

Note: Each command string can be separated with a space.

The following table lists the available Echo commands:

Command	Control	Enter	Description
echo	on	[Enter]	Turn on Echo function
echo	off	[Enter]	Turn off Echo function

Black Screen Command

The Black Screen command turns a display screen black when no source signal is detected. This prevents the display from showing the default blue or other color used when no source signal is detected.

The formula for the Black Screen command is as follows:

Command + Control + [Enter]

1. For example, to enable the Black Screen function, type:

   blackscreen on [Enter]

The following tables show the possible values for the **Black Screen** command:

Command	Description
blackscreen	Black Screen command

Control	Description
on	Turns Black Screen function on (default)
off	Turns Black Screen function off

Note: Each command string can be separated with a space.

The following table lists the available Black Screen commands:

Command	Control	Enter	Description
blackscreen	on	[Enter]	Turn on Black Screen function
blackscreen	off	[Enter]	Turn off Black Screen function

Read Command

The Read command allows you to view information about the device.

The formula for the Read command is as follows:

Command + [Enter]

1. To view information, type:

   read [Enter]

The following table shows the possible values for the **Read** command:

Command	Description
read	Read command

The following table lists the available Read commands:

Command	Enter	Description
read	[Enter]	Reads information from the device

The following is an example of the information the system will provide when the Read command is used:

read Command OK

o01 i03 video on audio on 1920x1080@60(1080p)

o02 i04 video off audio off bypass

o03 i02 video on audio off 1600x1200@60

Which means:

1. o01 i03 video on audio on 1920x1080@60(1080p)

Output 01 is connected to Input 03 with video and audio on; the resolution is scaled to 1080p at 60Hz

2. o02 i04 video off audio off bypass

Output 01 is connected to Input 03 with video audio off; scaling is bypassed (turned off)

3. o03 i02 video on audio off 1600x1200@60

Output 03 is connected to Input 02 with video on and audio off; the resolution is scaled to 1600x1200 at 60Hz

Reset Command

The Reset command allows you to reset the VM5404D / VM5808D to the default factory settings.

The formula for the Reset command is as follows:

Command + [Enter]

The following tables show the possible values for the **Reset** command:

Command	Description
reset	Reset command

Note: Each command string can be separated with a space.

The following table lists the available Reset commands:

Command	Enter	Description
reset	[Enter]	Resets the device settings

Baud Rate Command

The Baud Rate command allows you to set the RS-232 data rate for the VM5404D / VM5808D to use. Options are 9600, 19200 (default) 38400 and 115200.

The formula for the Baud Rate command is as follows:

Command + Control + [Enter]

1. For example, to set 38400 as the baud rate, type:

   baud 38400 [Enter]

The following tables show the possible values for the **Baud Rate** command:

Command	Description
baud	Sets the RS-232 baud rate

Control	Description
9600	Use 9600 baud rate
19200	Use 19200 baud rate (default)
38400	Use 38400 baud rate
115200	Use 115200 baud rate

Note: Each command string can be separated with a space.

The following table lists the available Baud Rate commands:

Command	Control	Enter	Description
baud	9600 / 19200 / 38400 / 115200	[Enter]	Sets the RS-232 baud rate

Save/Load Profile Command

The Save/Load Profile command allows you to save and load connection profiles. Saving profiles will save the connections currently in use.

The formula for the Save/Load Profile command is as follows:

Command + Profile + Number + Control + [Enter]

1. For example, to save the current connection configuration to profile 02, type:

   profile f 02 save [Enter]

The following tables show the possible values for the **Save/Load Profile** commands:

Command	Description
profile	Save / Load profile

Profile	Description
f	Profile command

Profile Number	Description
yy	VM5404D: 01-08 (default is 01)
	VM5808D: 01-16 (default is 01)

Control	Description
save	Save the connection configuration
load	Load a saved profile

Note: Each command string can be separated with a space.

The following table lists the available Save/Load Profile commands:

Command	Profile	Profile Number	Control	Enter	Description
profile	f	yy *	save	[Enter]	Save the connections as profile yy. VM5404D: (yy:01~08, *)
					VM5808D: (yy:01~16, *)
profile	f	yy *	load	[Enter]	Load profile yy. VM5404D: (yy:01~08, *)
					VM5808D: (yy:01~16, *)

OSD Command

To enable or disable the On-Screen Display (OSD) for displays, use the following command:

Command + Output + Number + Control + [Enter]

1. For example, to enable the OSD for output 07, type:

   osd o07 on [Enter]

2. For example, to disable the OSD for all outputs, type:

   osd o* off [Enter]

The following tables show the possible values for the **OSD** command:

Command	Description
osd	OSD command

Output	Description
o	Output port command

Number	Description
yy	Output port 01~16 port (default is 01)
*	All output ports

Control	Description
on	Enable OSD function
off	Disable OSD function (default)

Note: Each command string can be separated with a space.

The following table lists the available OSD commands:

Command	Output Command	Output Port	Control	Enter	Description
osd	o	yy *	on	[Enter]	OSD on for output yy yy:01~16, *
osd	o	yy *	off	[Enter]	OSD off for output yy (default) yy:01~16, *

Appendix

Safety Instructions

General

- Read all of these instructions. Save them for future reference.
- Follow all warnings and instructions marked on the device.
- This product is for indoor use only.
- Do not place the device on any unstable surface (cart, stand, table, etc.). If the device falls, serious damage will result.
- Do not use the device near water.
- Do not place the device near, or over, radiators or heat registers.
- The device cabinet is provided with slots and openings to allow for adequate ventilation. To ensure reliable operation, and to protect against overheating, these openings must never be blocked or covered.
- The device should never be placed on a soft surface (bed, sofa, rug, etc.) as this will block its ventilation openings. Likewise, the device should not be placed in a built in enclosure unless adequate ventilation has been provided.
- Never spill liquid of any kind on the device.
- Unplug the device from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
- The device should be operated from the type of power source indicated on the marking label. If you are not sure of the type of power available, consult your dealer or local power company.
- The device is designed for IT power distribution systems with 230V phase-to-phase voltage.
- To prevent damage to your installation it is important that all devices are properly grounded.
- The device is equipped with a 3-wire grounding type plug. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not attempt to defeat the purpose of the grounding-type plug. Always follow your local/national wiring codes.
- Do not allow anything to rest on the power cord or cables. Route the power cord and cables so that they cannot be stepped on or tripped over.

- If an extension cord is used with this device make sure that the total of the ampere ratings of all products used on this cord does not exceed the extension cord ampere rating. Make sure that the total of all products plugged into the wall outlet does not exceed 15 amperes.
- To help protect your system from sudden, transient increases and decreases in electrical power, use a surge suppressor, line conditioner, or un-interruptible power supply (UPS).
- Position system cables and power cables carefully; Be sure that nothing rests on any cables.
- Never push objects of any kind into or through cabinet slots. They may touch dangerous voltage points or short out parts resulting in a risk of fire or electrical shock.
- Do not attempt to service the device yourself. Refer all servicing to qualified service personnel.
- If the following conditions occur, unplug the device from the wall outlet and bring it to qualified service personnel for repair.
  - The power cord or plug has become damaged or frayed.
  - Liquid has been spilled into the device.
  - The device has been exposed to rain or water.
  - The device has been dropped, or the cabinet has been damaged.
  - The device exhibits a distinct change in performance, indicating a need for service.
  - The device does not operate normally when the operating instructions are followed.
- Only adjust those controls that are covered in the operating instructions. Improper adjustment of other controls may result in damage that will require extensive work by a qualified technician to repair.

Rack Mounting

- Before working on the rack, make sure that the stabilizers are secured to the rack, extended to the floor, and that the full weight of the rack rests on the floor. Install front and side stabilizers on a single rack or front stabilizers for joined multiple racks before working on the rack.
- Always load the rack from the bottom up, and load the heaviest item in the rack first.
- Make sure that the rack is level and stable before extending a device from the rack.
- Do not overload the AC supply branch circuit that provides power to the rack. The total rack load should not exceed 80 percent of the branch circuit rating.
- Make sure that all equipment used on the rack – including power strips and other electrical connectors – is properly grounded.
- Ensure that proper airflow is provided to devices in the rack.
- Ensure that the operating ambient temperature of the rack environment does not exceed the maximum ambient temperature specified for the equipment by the manufacturer.
- Do not step on or stand on any device when servicing other devices in a rack.

Technical Support

International

- For online technical support – including troubleshooting, documentation, and software updates: **http://eservice.aten.com**
- For telephone support, see *Telephone Support*, page iv:

North America

Email Support		support@aten-usa.com
Online Technical Support	Troubleshooting Documentation Software Updates	http://www.aten-usa.com/support
Telephone Support		1-888-999-ATEN ext 4988

When you contact us, please have the following information ready beforehand:

- Product model number, serial number, and date of purchase.
- Your computer configuration, including operating system, revision level, expansion cards, and software.
- Any error messages displayed at the time the error occurred.
- The sequence of operations that led up to the error.
- Any other information you feel may be of help.

Specifications

Function		VM5404D	VM5808D
Video Input	Interface	4 x DVI-D Female (White)	8 x DVI-D Female (White)
	Impedance	100 Ω	
	Max. Distance	1.8 m	
Video Output	Interface	4 x DVI-D Female (White)	8 x DVI-D Female (White)
	Impedance	100 Ω	
Video	Max. Data Rate	6.75 Gbps (2.25 Gbps Per Lane)	
	Max. Pixel Clock	225 MHz	
	Compliance	HDCP 1.4 Compatible	
	Max. Resolution	Up to 1920 x 1200	
	Max. Distance	Up to 5 m	
Control	RS-232	Connector: 1 x DB-9 Female (Black) Baud Rate and Protocol: Baud Rate: 19200, Data Bits: 8, Stop Bit: 1, Parity: No, Flow Control: No	
	IR	1 x Mini Stereo Jack Female (Black)	
	Ethernet	1 x RJ-45 Female (Black)	
EDID Settings		EDID Mode: Default / Port 1 / Remix	
Power	Connector	1 x 3-Prong AC Socket	
	I/P Rating	100-240VAC; 50-60Hz; 1.0A	
	Consumption	120VAC, 36.6W; 230VAC, 37.5W	120VAC, 56.4 W; 230VAC, 55.9W
Environment	Operating Temp.	0–50ºC	
	Storage Temp.	-20–60ºC	
	Humidity	0–80% RH, Non-condensing	
Physical Properties	Housing	Metal	
	Weight	3.50 kg	4.25 kg
	Dimensions (L x W x H)	43.20 x 26.20 x 4.40 cm	

Limited Warranty

IN NO EVENT SHALL THE DIRECT VENDOR'S LIABILITY EXCEED THE PRICE PAID FOR THE PRODUCT FROM DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, DISK, OR ITS DOCUMENTATION.

The direct vendor makes no warranty or representation, expressed, implied, or statutory with respect to the contents or use of this documentation, and especially disclaims its quality, performance, merchantability, or fitness for any particular purpose.

The direct vendor also reserves the right to revise or update the device or documentation without obligation to notify any individual or entity of such revisions, or update. For further inquiries, please contact your direct vendor.